



/

The products in this manual are industrial products and are all open-type housing designs. It is essential to install these products within a control cabinet that is safeguarded against dust, moisture, and accidents such as electric shocks or physical impacts. Additionally, protective measures must be taken to prevent malfunctions or damage caused by improper operation or accidents involving non-maintenance personnel. Failure to do so may lead to serious risks to personnel safety and potential loss of property.


M100

Please refer to the M100 series hardware operation manual for more detailed information.

 Batterie	M100	CPU	CR2430	5.3
	The M100 series CPUs are equipped with built-in CR2430 batteries. Replacement batteries must be purchased from HCFA. A professional electrical engineer, wearing insulated gloves and with power turned off, should replace them as described in Section 5.3.			
	Les CPU de la série M100 sont équipés de batteries CR2430 intégrées. Les batteries de remplacement doivent être achetées auprès de HCFA. Un ingénieur électrique professionnel, portant des gants isolants et avec le courant coupé, devrait les remplacer comme décrit dans la section 5.3.			

	Cooling method		Natural air cooling
	IP rating	IP20	IP20
	Enclosure material		Self-extinguishable

*
*Note: If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.





12
13
14

13 14

